POWER SUPPLY UNIT BPS-410, 24V/10A

AutroSafe Interactive Fire Detection System, Release 4 Product Datasheet

Features

- 24V/10A power supply
- Power Board BSF-400, including:
 - AutroFieldBus interface
 - 115VAC /230VAC input
 - 6 outputs 24VDC (max. 2A each)
- 1 fault relay output
- Transient protection
- Battery charging temperature compensated
- Electronic current limitation
- Conforms to CE standards
- Designed to meet IEC-61508 SIL2 requirements, C.E.N. EN 54-2, EN 54-4 and EN 54-13 regulations, FM regulations (Factory Mutual) and the maritime SOLAS requirements (Safety Of Life At Sea)

Description/Application

The power supply unit is prepared for decentralized power distribution via the AutroFieldBus to panels/units in the AutroSafe Interactive Fire Detection System, release 4 or later. Note that AutroFieldBus connections require shielded cable.

The unit can be mounted inside a 19" rack or consol. Note that, when connecting the power unit to an AutroSafe panel (BS-420) via AutroFieldBus, the panel will turn OFF the power on port C for a period of 3 seconds when the initialization starts.

Dipswitch Settings

Dipswitch settings for dipswitch S6 on Power Board BSF-400.

Dip- switch	Name	Description
S6-1	Earth Fault	ON: Earth fault monitoring activated OFF: Earth fault monitoring deactivated
S6-2	NA	Must be set to OFF (default)
S6-3	AutroFieldBus	ON: AutroFieldBus connected OFF: AutroFieldBus not connected
S6-4	NA	-
S6-5	Battery	Must always be ON Batteries must always be connected
S6-6	Power Unit Type	OFF: BPS-410



Part numbers to be used when mounted and delivered with other equipment

Part Number	Description		
116-BPS-410	BPS-410 PSU 24V/10A		
116-BPS-410/115	BPS-410 PSU 24V/10A 115VAC		

Part numbers to be used when boxed and delivered as a separate unit:

Part Number	Description		
116-BPS-410/BOXED	BPS-410 PSU 24V/10A BOXED		
116-BPS-410/115/BOXED	BPS-410 PSU 24V/10A 115VAC		
	BOX		



Techni	cal specifi	cations					
Dimen	sions (mm)	130x25	130x259x105			
Weigh	t (kg)		2,6kg	2,6kg			
Mount	ing		Surface	Surface mounting			
Materi	al		Steel br	Steel bracket			
Protec	tion class		Determ	Determined by the outer			
			enclosu	enclosure.			
Operat	ting Tempe	erature	-15°C to	-15°C to +70°C ⁵			
Storag	e Tempera	iture	-40°C to	-40°C to +70°C			
Humidit			Up to 95%	Up to 95% non-condensing			
Curren	t		115V 4,	115V 4,5A / 230V 1,9A			
Inrush	current			< 35A in 10ms			
Input v	oltage rar	nge					
115V r		-	230V ra	230V range			
94 - 13	-			184 – 264 VAC			
		45 –	66 Hz				
Outpu	t						
Max lo			Max loa	Max load without			
			battery	battery			
8A			10A				
Min ba	ttery size		Max ba	Max battery size			
12Ah	,		18Ah	-			
Accura	CY ¹						
<10m\	-						
Efficie	ncy						
		100% load					
Voltag							
19-32							
Overlo	ad protec	tion					
15A							
Shutdo	wn o/p. re	e-power on to	recover				
Fuses							
	y ² Fuse Na	me F7	Charge	r ² Fuse I	Name F8		
10A	,		10A				
	on data						
Fuses							
Name	Location	Electronic	Fuse	Туре	Special		
	10000000	fuse		.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	function		
F1	A1	Yes, 7A	2A	Fast			
F2	A2	Yes, 7A	2A	Fast			
F3	B1	Yes, 7A	2A	Fast			
F4	B2	Yes, 7A	2A	Fast	1		
F5	C1	Yes, 7A	2A	Fast	3		
F6	C2	Yes, 7A	2A 2A	Fast	3		
10	C2	1C3, /A	ZA	rast			

Cable parameters Output name Cable size max. A1 A2 Β1 Single thread 6mm² (10 AWG) B2 Multi thread 4mm² (12 AWG) C1 Minimum thread 0,2mm² (24 AWG) C2 Battery Charger AutroFieldBus Minimum Cat 5, shielded cable Dipswitch S5, AutroFieldBus earth fault sense S5.1 ON = earth sense to AFB CT A S5.2 ON = earth sense to AFB CT B S5.3 ON = earth sense enable **BSF-400** Current consumption 85mA

¹ The value is given in Volt peak to peak and this is converted to RMS.

² Miniblade fuses.

- ³ This port turns OFF for 3 seconds during initialization of AutroSafe if the Power Board BSF-400 is connected through AutroFieldBus.
- ⁴ If the battery port is short-circuited and the input AC voltage is 15% lower than the nominal voltage while maximum load is present, the DC voltage out may decrease to 14V for a period of 50ms.
- ⁵ Cooling is strongly recommended if the unit is placed in environments where the temperature during normal operation is likely to exceed +55°C for long periods of time. Note that batteries placed in high temperatures will have reduced lifetime and need to

Mounting / Dimensions

be replaced more often.

